



Unpack the mirror. Don't do this alone.

Install the 4 rubber feet supplied in the provided holes at the bottom of the frame.

When the mirror is delivered the wooden tablet is already placed on the frame. The frame is provided with a anti skid strip in order to avoid the tablet sliding out easily.

Don't move the mirror on your own.

