

Service Kits

		ZEON XP 10-S	ZEON XP 12-S	ZEON XP 14-S
KIT CONTENTS	DESCRIPTION	110100	110120	110140
6, 40, 60	DRUM ASSEMBLY	110976	110976	110976
10	BRAKE ASSEMBLY	89916	89916	89916
62	GROUND CABLE 2GA	98399	98399	98399
11	POWER CABLE 2GA	109452	109452	109452
61	HAWSE FAIRLEAD	100333	100333	100333
9, 36	DRIVESHAFT/COUPLER KIT	109662	109662	109662
31, 32	TIE PLATE	109675	109675	109675
47, 48	1ST STAGE PLANETARY SET	109774	109685	109695
45, 46	2ND STAGE PLANETARY SET	109696	109696	109698
42, 43, 44, 45	3RD STAGE PLANETARY SET	109699	109699	109699
37, 38	DRUM DRIVER SET	109705	109705	109705
29	12V CONTACTOR	98381	98381	98381
26	CONTROL PACK DUST BOOT	109707	109707	109707
4, 6, 7, 39, 40, 42, 45, 52, 56, 57	GASKET BUSHING KIT	109709	109709	109709
27, 31, 34, 35	TIE PLATE HARDWARE	109715	109715	109715
8, 13, 15, 21	MOTOR HARDWARE	109717	109717	109717
1, 8	MOTOR COVER	109718	109718	109718
2, 3, 13, 15, 21	MOTOR, 12V	111070	111070	111070
5, 21, 41, 6, 7, 39, 40, 8, 31, 4, 42	DRUM SUPPORT KIT	111068	111068	111068
8, 42, 45, 49, 50, 51, 52, 53, 55, 56, 57, 59	TRANSMISSION HOUSING	111407	111407	111407
51, 52, 54, 55, 56, 57, 58, 59	TRANSMISSION COVER AND REMOTE CLUTCH	109733	109733	109733
16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35	CONTROL PACK ASSEMBLY	111409	111409	111409
23, 24, 25, 26, 35	CONTROL PACK COVER	109734	109734	109734
12, 13, 14, 15	BUS BAR COVER KIT	109728	109728	109728
33, 34	DRUM LIGHT ASSEMBLY	109738	109738	109738
24 (all labels)	LABEL KIT	111410	111410	111410
Not shown	ROPE ASSEMBLY	87915	93120	93120
Not shown	REMOTE CONTROL	109732	109732	109732
Not shown	MOUNT/FAIRLEAD HARDWARE	109711	109711	109711
Not shown	SYNTHETIC ROPE HARDWARE	98526	98526	98526
Not shown	CONTROL PACK RELOCATION BRACKET	111141	111141	111141
Not shown	CONTROL PACK RELOCATION KIT - SHORT	111250	111250	111250
Not shown	CONTROL PACK RELOCATION KIT - LONG	111394	111394	111394

