


FITTING INSTRUCTION

| Clamp mark in acc. with | | Cables joining |
|-------------------------|-----|---------------------------|
| ISO | PN | |
| 1 | L | Left directional lights |
| 2 | + | Rear fog lights |
| 3 | 31 | Ground |
| 4 | R | Right directional lights |
| 5 | 58R | Right side parking lights |
| 6 | 54 | Stoplights |
| 7 | 58L | Left side parking lights |



This towbar is designed to assembly in following car:
LAND ROVER FREELANDER, (LN), produced since 03.1998 till 09.2006, catalogue no. **LN01** and is prepared to tow trailers max total weight **2000 kg** and max vertical load **140 kg**.

From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towbar depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towbar should be install in points described by a car producer.

The instruction of the assembly

1. From the right side of the frame disassemble original tow eye (not used any more).
2. Put the main bar of the towbar (pos. 1) to the frame that way, so holes (pos. A) agree to threaded holes and fix using bolts M10x35mm (pos. 6), and next through holes (pos. B) fix using bolts M12x1,25x70mm (pos. 5).
3. Fix tow-ball (pos. 2) and socket plate (pos. 3) using bolts M12x75mm (pos. 4a) and M12x70mm (pos. 4b) from accessories.
4. Tighten all bolts according to the torque shown in the table.
5. Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station).
6. Complete the paint coating damaged during instalment.

Torque settings for nuts and bolts (8,8):

| | | |
|--------------------|---------------------|---------------------|
| M6 - 11 Nm | M8 - 25 Nm | M10 - 50 Nm |
| M12 - 87 Nm | M14 - 138 Nm | M16 - 210 Nm |

NOTE







After install the towbar you should get adequate note in registration book (at authorised service station).The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km of exploitation check all bolts and nuts. The ball of towbar must be always kept clear and conserve with a grease.



Towbar accessories:

| | | |
|--|---|--|
| Pos. 1 Name: Main bar Quantity: 1  | Pos. 4a Name: Bolt 8,8 B Quantity: 1 Dim.: M12x75mm  | Pos. 8 Name: Plain washer Quantity: 4 Dim.: Ø 13 mm  |
| | Pos. 4b Name: Bolt 8,8 B Quantity: 1 Dim.: M12x70mm  | Pos. 9 Name: Plain washer Quantity: 6 Dim.: Ø 10,5 mm  |
| Pos. 2 Name: Tow ball Quantity: 1  | Pos. 5 Name: Bolt 8,8 B Quantity: 2 Dim.: M12x1,25x70mm  | Pos. 10 Name: Spring washer Quantity: 4 Dim.: Ø 12,2 mm  |
| Pos. 3 Name: Socket plate Quantity: 1  | Pos. 6 Name: Bolt 8,8 B Quantity: 6 Dim.: M10x35mm  | Pos. 11 Name: Spring washer Quantity: 6 Dim.: Ø 10,2 mm  |
| | Pos. 7 Name: Nut 8 B Quantity: 2 Dim.: M12  | Pos. 12 Name: Ball cover Quantity: 1  |

Towing hitch (without electrical set)

Class: **A50-X** Cat. no. **LN01**

Designed for:

Manufacturer: **LAND ROVER**

Model: **FREELANDER**

Type: **(LN)**

produced since 03.1998 till.09.2006

Technical data:

D-value: 10,0 kN

maximum trailer weight: **2000 kg**

maximum vertical cup load: **140 kg**

Approval number acc. to regulations EKG/ONZ 55.01: E20-55R-01 1105

Foreword

This towbar is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch.

The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving whereat values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]} \times \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \text{Max vehicle weight [kg]}} \times \frac{9,81}{1000} = D \text{ [kN]}$$