## Towing hitch accessories:

10 wing meet decessories.					
Pos.: 1	Pos. Left bracket  5  Pcs.: 1	Pos. Bolt 8,8 B M12x1.25x40mm			
	Pos. 6 Fish-plate 1 Pcs.: 2	Pos. Bolt 8,8 B 11 M12x35mm PCS.: 2			
Pos. Tow ball (mounting set)  PCS.:1	Pos. 7 Fish-plate II Pcs.: 2	Pos. Nut 8 B 12 M12 PCS.: 2			
Pos.: 1	Pos. Distance sleeve #25x4mm L=8mm PCS: 2	Pos. Plain washer 913mm PCS.:12			
Pos. Right bracket  Pcs.: 1	Pos. 9 M12x50mm PCS.: 2	Pos. Spring washer #12,2mm  PCS.:12			



## PPUH AUTO-HAK Sp.J.

Produkcja Zaczepów Kulowych Henryk & Zbigniew Nejman 76-200 SŁUPSK ul. Słoneczna 16K tel/fax (059) 8-414-414; 8-414-413 E-mail: office@autohak.com.pl www.autohak.com.pl

# **Towing hitch (without electrical set)**

Class: A50-X Cat. no. **Z26A** 

Designed for:

Manufacturer: MITSUBISHI

Model: PININ

Type: **5 doors (H70)** 

produced since 08.2000 till 06.2007

Technical data: **D**-value: **8.1 kN** 

maximum trailer weight: **1500 kg** maximum vertical cup mass: **75 kg** 

Approval number according to Directive 94/20/EC: e20\*94/20\*1039\*00

#### **Foreword**

This towing hitch is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch.

The vehicle manufacturer's specifications regarding trailer mass and max. vertical cup mass are decisive for driving whereat values for the towing hitch cannot be exceeded.

 $D ext{-}value\ formula:$ 

$$\frac{\text{Max trailer weight [kg]} \quad \text{x} \quad \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \quad \text{Max vehicle weight [kg]}} \text{X} \quad \frac{9,81}{1000} = \quad D \text{ [kN]}$$

#### FITTING INSTRUCTION

TOO	p mark c. with	Cables joining	10
ISO	PN L	Y O P 11:1-	7 /  \
2	<u>L</u> +	Left directional lights Rear fog lights	\ a67\$  \
3	31	Ground	8
4	R	Right directional lights	0 0000
5	58R	Right side parking lights	
6	54	Stoplights	
7	58L	Left side parking lights	6 _ A ¬
	7 _	6 _	
		$\mathbf{A} \supset \mathbf{A}$	

This towing hitch is designed to assembly in following cars: **MITSUBISHI PININ**, **5 doors (H70)**, produced since 08.2000 till 06.2007, catalogue no. **Z26A** and is prepared to tow trailers max total weight **1500 kg** and max vertical mass **75 kg**.

## From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towing hitch depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towing hitch should be install in points described by a car producer.

### The instruction of the assembly

- 1. Unscrew bolts of the towing eye from the left chassis member, then fix loosely bracket (pos. 5) and fish-plate (pos. 7) using bolts M12x1.25x40mm (pos. 12). Place distance sleeve (pos. 8) as showed on the drawing.
- 2. Fix loosely bracket (pos. 4) and fish-plate (pos. 7) to the right chassis member using bolts M12x1.25x40mm (pos. 12). Place distance sleeve (pos. 8) as showed on the drawing.
- 3. Put the main bar of the towing hitch (pos. 1) between brackets (pos. 4 and 5) and fix it using bolts M12 as showed on the drawing.
- 4. Fix fish-plates (pos. 6) to inside the chassis members through holes pos. A (see the drawing).
- 5. Fix tow-ball (pos. 2) according to the instruction.
- 6. Tighten all bolts according to the torque shown in the table.
- 7. Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station).
- 8. Complete paint layer damaged during installation.

Torque settings for nuts and bolts (8,8):				
<b>M6</b> - 11 Nm	<b>M 8 -</b> 25 Nm	<b>M 10 -</b> 50 Nm		
<b>M 12 -</b> 87 Nm	<b>M 14 -</b> 138 Nm	<b>M16</b> - 210 Nm		

### **NOTE**

After installation of a towing hitch you should get adequate note in registration book (at authorised service station). The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km of exploitation check all bolts and nuts. The ball of towing hitch must be always kept clear and conserve with a grease.